

F. Atlee Dodge Aircraft Services, LLC.

6672 Wes Way * Anchorage, Alaska 99518
Phone: (907) 344-1755 * Fax: (907) 344-6720
atleedodge@acsalaska.net ~ www.fadodge.com

INSTRUCTIONS FOR CONTINUED AIRWORTHINESS

Safari Seat Piper PA18 Series Aircraft

RETAIN THIS DOCUMENT WITH THE AIRCRAFT RECORDS

Document Number: ICA-1018

REVISION HISTORY

Revision	Description	Date
IR	Initial Release (IR) for AEG Review.	07-14-2009

exe;

For updated revisions of this document it is the owner/operators responsibility to contact F. Atlee Dodge Aircraft Services, LLC. through our website or directly at the numbers given above.

This document meets the requirements of 14 CFR 23.1529 (Appendix G).

Additionally it is found acceptable to the FAA AEG in accordance with the guidelines outlined in FAA Order 8110.54.

Information contained herein is the property of F. Atlee Dodge
Aircraft Services, LLC.

Copy or reproduction, manual or electronic, is not authorized
without prior written consent.

Doc. No.:	1018
Revision:	IR
Date:	July 14 .2009
Page	1 of 6

TABLE OF CONTENTS

1	Mod	lel Applicability	3
		lification Description	
		Illustrated Parts	
		Parts List	
3	Insta	allation and Removal Procedures	5
		Installation	
	3.2	Removal	5
		ntenance	
		Inspection Requirement	
		vorthiness Limitations	

Information contained herein is the property of F. Atlee Dodge
Aircraft Services, LLC.
Copy or reproduction, manual or electronic, is not authorized
without prior written consent

Doc. No.:	1018
Revision:	IR
Date:	July 14 .2009
Page	2 of 6

1 Model Applicability

The data presented in this Instruction for Continued Airworthiness (ICA) is intended to augment the information contained in the original aircraft maintenance manual or structural repair manual. Additional information on recommended best practices and acceptable methods, techniques can be obtained from a current version of FAA Advisory Circular (AC) 43.13-1B/2A.

Make/Model	TCDS	Certification Basis (per TCDS)	Comments
Piper	A-799	CAR 3, 11/1/49, 3-1	
PA-18, PA-18S, PA-18			
"105" (Special), PA-18S			
"105"(Special), PA-18A, PA-			
18 "125"(Army L-21A),		·	
PA-18AS "125", PA-18S			
"125", PA-18 "135" (Army			
L-21B), PA-18A "135", PA-			
18S "135", PA-18AS "135",			
PA-18 "150", PA-18A "150",			
PA-18S "150, PA-18AS			
"150", PA-19 (Army L-18C),			
PA-19S			

Information contained herein is the property of F. Atlee Dodge	Doc. No.:	1018
Aircraft Services, LLC.	Revision:	IR
Copy or reproduction, manual or electronic, is not authorized without prior written consent.	Date:	July 14 .2009
	Page	3 of 6

2 Modification Description


NOTE:

The rear seat installation does not include an approved seat belt. It is the owner/operators responsibility to obtain and install an appropriately rated seat belt.

This modification consists of removal of the original rear seat and installing Rear folding "Safari" Seat. The safari seat will bolt onto existing fuselage tubes with a specially made seat clamp weldment (6151-03) at each of the four seat corners. Once these clamps are installed the seat back, bottom or both can be removed by pulling the J900002-001 Pins.

The seat back (6151-02) must be secured to the *rear cross bar* in flight. It is suggested that a Velcro strap be used.

2.1 Illustrated Parts



	Doc. No.:	1018
Aircraft Services, LLC.	Revision:	IR
Copy or reproduction, manual or electronic, is not authorized without prior written consent.	Date:	July 14 .2009
without prior written consent.	Page	4 of 6

2.2 Parts List

Part Description	Part Number	Quantity	Comments
Seat Back	6151-02	1	FAA/PMA'd
Seat Bottom	6151-01	1	FAA/PMA'd
Clamps	6151-03	4	FAA/PMA'd
Pins	J90002-001	6	Supplied in kit
AN4-7A	Bolts	4	Supplied in kit
MS21044N4	Nut	4	Supplied in kit
AN960-416L	Washers	8	Supplied in kit
Velcro Strap		18"	Local Purchase

3 Installation and Removal Procedures

NOTE:

These procedures are based on existing rear seat removed from aircraft.

3.1 Installation

- 1. Install P/N 6151-03 clamps on front (STA 48.75) and rear (STA 69.75) seat tubes. DO not tighten at this time.
- 2. Position seat bottom P/N 6151-01 on clamps using 4 pins P/N J90002-001. Center seat on tubes.
- 3. Tighten clamp to 30 in-lbs torque.
- 4. Install seat back P/N 6151-02 using pins P/N. J90002-001 on lower tube of seat back. Secure top of seat back to rear seat upper cross bar with velcro straps.

3.2 Removal

- 1. Take out seat back by removal of pins (2x). Store with seat back.
- 2. Take out seat bottom by removal of pins (2x). Store with seat bottom.
- 3. Remove clamps as by removing AN4 bolts. Store with seat bottom.

Information contained herein is the property of F. Atlee Dodge	Doc. No.:	1018
Aircraft Services, LLC.	Revision:	IR
Copy or reproduction, manual or electronic, is not authorized without prior written consent.	Date:	July 14 .2009
without phot written consent.	Page	5 of 6

4 Maintenance

If repairs are required to seat back, bottom or clamps, contact F. Atlee Dodge Aircraft Services, LLC. by telephone at 907-344-1755.

4.1 Inspection Requirement

The seat back, bottom, clamps and fuselage tubes should be inspected, for wear, damage or deformation on a 100HR/annual or progressive basis in accordance with the applicable maintenance manual and replace hardware as required.

5 Airworthiness Limitations

This Airworthiness Limitations Section is FAA approved and specifies maintenance required under paragraphs 43.16 and 91.403 if the Federal Aviation Regulations unless an alternate program as been FAA approved. This modification does not affect the airworthiness section of the FAA Approved Maintenance Manual.

No additional airworthiness limitations have been imposed by this modification.

END

Information contained herein is the property of F. Atlee Dodge	Doc. No.:	1018
Aircraft Services, LLC.	Revision:	IR
Copy or reproduction, manual or electronic, is not authorized without prior written consent.	Date:	July 14 .2009
without phot written consent.	Page	6 of 6